

WESDAR

WESDAR K50 Bluetooth Speaker 藍芽揚聲器

FM Radio Operation FM 收音機操作

[In English]

1. Insert the provided Micro USB cable as an external antenna at a good signal area
2. Press "on/off" button to enter FM mode
3. Press "+/-" to select channels

[中文]

1. 插入提供的 Micro USB 充電線作為接收天線之用並處於接受良好的範圍
2. 按下 "on/off" 鍵以進入 FM 模式
3. 按下 "+/-" 鍵以選擇頻道

Instruction written by Beetles Design. August 2020.